


Cisco 7916 Side Car User Guide



Busy Lamp Field / Line Buttons

	Green, steady —Active call or two-way call
	Green, flashing —Held call
	Amber, steady —Privacy in use or one-way intercom call
	Amber, flashing —Incoming call or reverting call
	Red, steady —Remote line in use
	Off , line available for use

Shift Buttons

Shift Buttons— 2 buttons.

Each button corresponds to one page of 12 line keys.

Page one is labeled with the number

1 and page two is labeled with the number 2.

The lights beneath each button indicate the state of the page as follows:

- Page is active: steady green light
- Page is inactive: light off
- A call is ringing on an inactive page: flashing amber light

Call Status Icons

Icon Line or call state Description

- On-hook line No call activity on this line.
- Off-hook line You are dialing a number Connected call
- You are connected to the other party.
- Ringing call A call is ringing on one of your lines.
- Call on hold You have put the call on hold.
- Remote-in-use Another phone that shares your line has a connected call.

Using a Shared Line

- BLF- monitored line is idle
- BLF- monitored line is in-use
- BLF- monitored line is Ringing (BLF Pickup)
- BLF-Line in Do Not Disturb (BLF feature)
- Idle Intercom line -intercom line is not in use.
- One-way intercom call-The intercom line is sending or receiving one-way audio.
- Two-way intercom call-The recipient pressed the intercom line to activate two-way audio with the caller.