




Cisco 6941& 6945 User Guide

Busy Lamp Field / Line Buttons

- Amber —Ringing call on this line
- Green —Active or held call on this line
- Red —Shared line in-use remotely



Application Button 

Contacts Button 

Voicemail Button 

Transfer Button 

Hold Key Button 

Conference Button 

Volume Toggle 

Speaker Button 

Mute Button 

Headset Button 

Navigation Button 

Release Button 

Basic Call Handling

INTERNAL DIALING

- Dial the 4 digit extension .
- Calls between 831 numbers will be 4 digit dial.
- Calls between 837 numbers will be 4 digit dial.
- Calls from 831 to 837 will be 5XXXX.
- Calls from 837 to 831 will be 5XXXX.
- Callers in Lewis can dial 55 + 4 digit extension
- For further dialing instructions follow the link <http://www.udel.edu/TelephoneServices/dialing-instructions.html>

EXTERNAL DIALING

- Local: 9+ Number
- Domestic: 9+1 Area Code + Number
- International: 9+011+Country Code+Number
- **Emergency External 911 & 9911**

BASIC CALL PLACING OPTIONS

- Pick up the handset.
- Press the **Call** or **Redial** icon.
- Press the Speakerphone button.
- Press a **Speed Dial button**.


ANSWERING CALLS

While idle:

- Lift the handset
- Press the speakerphone button
- Press the amber flashing session button

HOLD/RESUME

While on an active call:

1. Press the **Hold** key. 
2. Press the **Resume** softkey.

CALL JOIN

During an Active call, if a second calls rings in

You will hear a single beep

To Answer (the original call will be put on hold automatically)


- Press the flashing amber line button

Or

- Select the **Answer** softkey.

CALL JOIN



Start with two connected calls.

1. Make sure that one of the calls is active (not on hold). If both calls are on hold, resume one call.
2. Press the **Conference** button .
3. Press the line button for the other (held) call.

Transfer Options

BLIND TRANSFER

While in an active call:

1. Press the **Transfer** key. 
2. Dial the intended party.
3. Press the **Transfer** key  again to complete the transfer.

CONSULT TRANSFER

While in an active call:

1. Press the **Transfer** key.
2. Dial the intended party.
3. Wait for the party to answer and announce the call, press the **Transfer** key again to complete the transfer.
4. If dialed party does not wish to take the call, press **End Call** (red hardkey), then resume the original call.


TRANSFER TO VOICEMAIL

1. Press the **Transfer** key.
2. Dial * plus the 4 or 5 digit extension.
3. Press **Transfer** again.

Conferencing Options

AD-HOC CONFERENCING (MAX 6)

While in an active call:

1. Press the **Conference** key. 
2. Dial the intended party.
3. Press the **Conference** key again to complete the conference.
4. Repeat to add additional parties.

VIEW CONFERENCE PARTICIPANTS

While in an Ad-Hoc or Joined Conference call:

1. Press **show detail** icon.
2. To refresh the screen participants, press the **Update** icon.

REMOVE CONFERENCE PARTICIPANTS

While in an Ad-Hoc or Joined Conference call:

1. Press **Show Detail** Icon.
2. Highlight the party you wish to remove using the toggle button.
3. Press the **Remove** icon.

Call Forwarding

To activate:

1. Press the **ForwardAll** icon.
2. Dial the desired destination.
3. To deactivate: Press the **Forward Off** icon.

Intercom (Speaker Call)

To Intercom

- Press the intercom button
- Enter the desired extension

The Receiving Extension

- Press the Intercom button or the originator of the speaker call will not be able to hear you
- Note if the receiving extension is on the phone
You can whisper the message your message without the Person they are talking to hearing you.

Voicemail

ID & PIN

Internally from your own phone:

Press the Message Key

The “default” PIN is “159357”

You will be prompted to change it during initial set up.

INITIAL SETUP

Follow the prompts to setup your mailbox

“Record your name”

“Record your greeting”

“Change your temporary PIN”

“Change your “Directory” listing”

If you “hang up” before you have completely enrolled, you will have to repeat the setup process next time you access voicemail.

INTERNAL ACCESS

Internally from another phone:

1. Press the Message envelope
Or Dial extension “4000 or 7000”
2. Enter 4-digit extension #
3. Enter your PIN & #

EXTERNAL ACCESS

1. Dial
2. Press the “★” key
3. Enter 7-digit (831-XXXX) extension, #
4. Enter your PIN & #.

MAIN MENU

- 1- Listen to messages
- 2- Send a message
- 3-Review old messages
- 4-Setup options

PERFORMING COMMON TASKS

- 4-1-1 Re-Record Standard Greeting
- 4-1-2 Re-Record Alternate Greeting
- 4-3-2 Re-Record Name
- 4-3-1 Change Pin

LISTENING TO MESSAGES

- 1- Listen to new messages
- 3- Listen to old messages

[1][1] Rewind to beginning of message

WHILE LISTENING TO MESSAGES

[3] Delete

[4] Slower

[6] Faster

[#] Skip

AFTER LISTENING TO MESSAGES

- [1] Repeat Message
- [2] Save Message
- [3] Delete Message
- [4] Reply to Message
- [5] Forward a Message
- [6] Save message as new
- [7] Go back 5 seconds
- [8] Pause/Restart
- [9] Message Properties
- [#][#] Skip to next message
- [*] Cancel playing messages
- [1] [4]-Previous Message
- [1][6] Next Message

NOTES or Help Desk INFO
