

Cisco 7945 User Guide



- 1 Line activation-Buttons
7945: 2 Programmable Buttons
- 2 Foot Stand Button
- 3 Display Buttons
- 4 Messages Button
- 5 Directories Button
- 6 Help Button
- 7 Settings Button
- 8 Services Button
- 9 Volume Button
- 10 Speaker Button
- 11 Mute Button
- 12 Headset Button
- 13 4-way Navigation Button
- 14 Keypad
- 15 Softkey Buttons
- 16 Voicemail lamp/Phone lamp
- 17 Phone Screen (Touch Screen for 7975)

Busy Lamp Field/Line Buttons

- **Green, steady**—Active call or two-way call
- **Green, flashing**—Held call
- **Amber, steady**—Privacy in use or one-way intercom call
- **Amber, flashing**—Incoming call or reverting call
- **Red, steady**—Remote line in use
- **Off**—line available for use

Basic Call Handling

To view basic dialing instructions, see the following website:
<http://www.udel.edu/voip/dialing.html>

BASIC CALL PLACING OPTIONS

- Pick up the handset.
- Press the **Call** or **Redial** icon.
- Press the **Speaker** button.
- Press a **Speed Dial** button.

ANSWERING CALLS

While idle:

- Lift the handset.
- Press the **Speaker** button.
- Press the amber flashing button.

HOLD/RESUME

While on an active call:

1. Press the **Hold** softkey.
2. Press the **Resume** softkey.

Call Waiting

During an active call, if a second call rings in, you will hear a single beep. To answer, press the **Answer** softkey (the original call will be placed on hold automatically).

CALL JOIN

Start with two connected calls.

1. Make sure that one of the calls is active (not on hold). If both calls are on hold, resume one call.
2. Highlight the call on hold.
3. Press **More** softkey.
4. Press **Join**.

Transfer Options

BLIND TRANSFER

While in an active call:

1. Press the **Transfer** button.
2. Dial the intended party.
3. Press the **Transfer** button again to complete the transfer.

CONSULT TRANSFER

While in an active call:

1. Press the **Transfer** button.
2. Dial the intended party.
3. Wait for the party to answer and announce the call. Press the **Transfer** button again to complete the transfer.
4. If dialed party does not wish to take the call, press **End Call**, then resume the original call.

TRANSFER TO VOICEMAIL

1. Press the **Transfer** button.
2. Dial * plus the 4-digit extension.
3. Press **Transfer** again.

Conferencing Options

AD-HOC CONFERENCING (MAX 6)

While in an active call:

1. Press **More**.
2. Press the **Conference** button.
3. Dial the intended party.
4. Press the **Conference** button again to complete the conference.
5. Repeat to add additional parties.

VIEW CONFERENCE PARTICIPANTS

While in an Ad-Hoc or Joined Conference call:

1. Press **More**.
2. Press the **Conflist** softkey.
3. To refresh the screen participants, press the **Update** button.

REMOVE CONFERENCE PARTICIPANTS

While in an Ad-Hoc or Joined Conference call:

1. Press **More**.
2. Press the **Conflist** softkey.
3. Highlight the party you wish to remove using the toggle button.
4. Press the **Remove** softkey.

Call Forwarding

To activate:

1. Press the **CFwdAll** softkey.
2. Dial the desired destination. Don't forget to include 9+1 if forwarding to an external number.
3. To deactivate: Press the **CFwdAll** softkey.

To Forward Calls to Voicemail:

1. Press the **CFwdAll** softkey.
2. Press the **Messages** button.

Intercom (Speaker Call)

To Intercom

- Press the **Intercom** button.
- Enter the desired extension.

The Receiving Extension

- Press the **Intercom** button or the originator of the speaker call will not be able to hear you. Note: If the receiving extension is on the phone, you can whisper your message without the person they are talking to hearing you.

Cisco 7945 Voicemail Set Up

ID & PIN

Internally from your own phone:

Press the **Message** button.

INITIAL SETUP

Follow the prompts to setup your mailbox:

“Record your name”

“Record your greeting”

“Change your temporary PIN”

The “default” PIN is **“159357”**

You will be prompted to change it during initial set up.

If you “hang up” before you have completely enrolled, you will have to repeat the setup process next time you access voicemail.

INTERNAL ACCESS

Internally from another phone:

1. Press the Message envelope
2. Press the Asterisk *
3. Enter 7-digit extension # (831-XXXX)
4. Enter your PIN & #

EXTERNAL ACCESS

1. Dial your number
 2. Press the Asterisk *
 3. Enter 7-digit number (831-XXXX), #
 4. Enter your PIN & #
-

VOICEMAIL PROMPTS

To view a list of the common voicemail prompts, see the following website:

<http://www.udel.edu/voip/voicemail.html>